

A multi-purpose, neutral pH, germicidal detergent and deodorant that disinfects, cleans and deodorizes walls, metals and other non-porous surfaces in one labor saving step. Effective against Trichophyton mentagrophytes, Candida albicans, HIV-1 (AIDS virus), Influenza A/Hong Kong, Herpes Simplex Type 1, Herpes Simplex Type 2, Vaccinia, Rubella (German Measles), Adenovirus type 4, Canine Distemper, and Escherichia Coli (ATCC & antibiotic resistant strain). Ask for product data sheet for additional pathogens.



Where To Use

| | | | |
|---------|--------------------|----------------|-----------|
| Schools | Nursing Homes | Hospitals | Restrooms |
| Hotels | Veterinary Clinics | Airports | |
| Kennels | Office Buildings | Dumpster Areas | |

Dilution

1/64 (2 oz./gallon)

Directions

For general cleaner - Remove heavy soil deposits from surface. Then thoroughly wet surface with a solution of 2 ounces of the concentrate per gallon of water. The solution can be applied with a cloth, mop, sponge or coarse spray or soaking. Let solution remain on surface for a minimum of 10 minutes. Rinse and allow to air dry.

For toilet bowl - Swab bowl with brush to remove heavy soil prior to cleaning and disinfecting. Clean by applying dilution around the bowl and up under the rim. Stubborn stains may require brushing.

For disinfecting - first remove or expel over the inner trap the residual bowl water. Pour in three ounces of the dilution. Swab the bowl completely using a scrub brush or mop, make sure to get under the rim. Let stand for 10 minutes or over night, then flush.

For decontamination against HIV-1 (AIDS virus) of surfaces/objects soiled with blood/body fluid. Disposable latex or vinyl gloves, gowns, face mask or eye coverings must be worn during all cleaning of body fluids, blood and decontamination procedures. Blood and body fluids must be thoroughly cleaned from surfaces and objects before application of disinfectant. Effective against HIV-1 (AIDS virus) on hard nonporous surfaces in the presence of a moderate amount of organic soil (5% blood serum) (providing 1800 ppm of active quaternary) for a contact time of 4 minutes at room temperature. Use a 10 minute contact time for disinfection against all other bacteria, fungi and viruses claimed (listed on product data sheet).

Technical Specifications

| | | | |
|------------------|------------------------------|--------------------|--------------------|
| COLOR: | Transparent Colorless | EPA Reg No:..... | 47371-131-18305 |
| FORM: | Liquid | STORAGE(Unopened): | 1 Year @R.T. |
| SCENT: | Pine | BIODEGRADABLE: | Yes |
| pH: | 7.5 | WEIGHT/GAL: | 8.4 lbs. |
| FLASH POINT:.... | None | SHIPPING CLASS: . | None |
| VISCOSITY: | Water Thin | PACKAGING: | 4x1, 5 gal, 55 gal |
| FOAM: | Low/Medium | HOSPITAL GRADE: . | Yes |
| | | HIV CLAIM..... | Yes |
| TYPE: | Pine Scented Neutral pH Quat | | |

